

Replacing Ladder Feet

Extension Ladder Feet



1. Drill Rivets



2. Remove Foot



3. Replace Foot



4. Rivot Foot

Articulated Feet



1. Use a 13mm spanner to unfasten the nut and bolt



2. Take the old foot out of the metal bracket



3. Replace the foot using the nut and bolt, make sure the brass insert is in place



4. Tighten the nut and bolt until secure

Bolted Step Feet



1. Unbolt and remove old foot. Put a new foot in and Drill a M6 through the hole and foot.



2. Insert the bolt through the hole.



3. Thread the nut onto the bolt and secure with a spanner and driver at each side.

Please call **01792 796 666** for assistance

Safety

- **Please ensure all repairs are carried out by a competent person.**
- **Please ensure appropriate PPE is worn whilst carrying out repairs**
- **Please use the correct tools for the job**
- **If in doubt please contact Lyte for guidance**

Please call [01792 796 666](tel:01792796666) for assistance